
## ACBL520-1



For replacement parts contact:

AØ Á Á Á

## L520-1 LC520 (cont'd)

Key No.	Part Number	<u>Drescription</u>
	CAC-322	Belt guard, outside
1	CAC-323	
2		Belt guard, inside
3	SSF-8113-ZN CAC-327	Lock nut
4		Bracket
5	• CAC-4029	Compressor Pump Assy.
6	265-17	Intake filter
7	265-18	Filter Retainer
8	SSF-935	Screw, #8-32 x 3/8" (2 used)
9	CAC-61	Ring, Panel Mounting
10	SSP-7812	Nut Sleeve Assy. 1/2" (2 used)
11	AC-0041	Outlet Tube
12	97503734	Safety Valve ASME
13	AC-0010	Guage, LT Hand
14	SSP-7811	Nut Sleeve Assy. 1/4" (2 used)
15	AC-0028	Pressure Release Tube
17	AC-0007	Pressure Regulator
18	H-2101	Adapter
21	AC-0027	Manifold
22	AC-0009	Gauge, RT Hand
23	DAC-187	Cord Assembly
25	SS-8553	Connector Body
26	AC-0008-1	Pressure Switch Assembly
27	CAC-4215-1	Motor Cord Assembly
28	SSP-480	Nipple
29	CAC-4337	Check Valve
30	SSF-928	Screw 5/16"-18 x 7/8" (4 used)
31	CAC-1013	Hold-down Screw
32	CAC-1012	Hold-down Plate
33	CAC-1011	Elastomer Spring
34	SSN-56-ZN	Washer
35	SSN-1619-ZN	Lockwasher
36	SS-2038-ZN	Wing Nut
37	CAC-320-1	Handle
38	CAC-1059	Retaining Clip (2 used)
39	SUDL-6-1	Rubber Foot Strip
40	CAC-60	Shoulder Bolt (2 used)
41	AC-0014	9" Wheel (2 used)
42	SSF-8080-ZN	Nut (2 used)
43	SS-2707	Drain cock
47	D21594	Motor pin
48	MO-3013-1	Motor
49	SUDL-65	Motor shaft key (3/16" x 3/16" x 1 1/4")
50	C-PU-2861	Motor pulley
51	SS-391	Set screw
52	C-BT-223	Poly-V-Belt, 39" long
53	SSF-986	Self-tapping screw (2 used)
54	AC-0011	Console Cover

•See Pumps Tab

Not Shown (L520-1)

MG3-OLPORT-3A

MP3-L520-2

ÁAZ[¦Á^] |æ&^{ ^} ¢Á, 梢 Á8[} ææ&dÁWWXXIII] 梢 ÁÒ˘ˇ ∄{ ^} ¢Áp &ÀXIB&^••[¦ã∿ ÁQ &ÀXWWWWWWWIII-877-475-5660 ÁWWWWWWW, ¸¸Èæ|] 梢 ∄ &È&[{

Operators Manual

Parts Manual

Not Shown (LC520)

MG3-OLPORT-3A

D22288

Operators Manual

Parts Manual